

# LLS100 LED TUBE SERIES



# FEATURES AND BENEFITS

- Single Ended Power
- No Ballast Required
- 10 Year Warranty
- Made in the USA
- Aluminum Construction / Polycarbonate



### SPECIFICATIONS

- Length Color Temperature Lens Input Voltage Connection Driver CRI Dimming Lifetime Temperature Rating Regulatory Warranty
- 2' / 3' / 4' 3500K, 4000K and 5000K Frosted and Clear 120-277VAC 50/60Hz Medium Bi-Pin G13 Single Ended Power >80 Non-Dimmable Rated Life of 50,000 Hrs (L70) Operating Temp -20 to +50° C UL, cUL, DLC, IGRR 10 Years



\* Non-Shunted Tombstones Required

\* Turn off power before Installing LED Tube



©LEDLIGHTINGSOLUTIONS


**DIRECT**.410.320.0200 **OFFICE**.855.309.1702

FAX.941.296.7313

WWW.LEDLIGHTINGSOLUTIONS.COM

All rights reserved. LED Lighting Solutions reserves the right to change specifications for product improvement without prior notice.





#### **PRODUCT BREADOWN**

Part Number	Size	Power	Lumens	Voltage	Power Factor	Direct Wire
LLS100-24-35-08-FUSA	24"	8	1180	120/277VAC	>0.95	YES
LLS100-24-40-08-FUSA			1200			
LLS100-24-50-08-FUSA			1200			
LLS100-48-35-11-FUSA	48"	11	1620	120/277VAC	>0.95	YES
LLS100-48-40-11-FUSA			1650			
LLS100-48-50-11-FUSA			1650			
LLS100-48-35-13-FUSA	48"	13	1939	120/277VAC	>0.95	YES
LLS100-48-40-13-FUSA			1950			
LLS100-48-50-13-FUSA			1950			
LLS100-48-35-15-FUSA	48"	15	2180	120/277VAC	>0.95	YES
LLS100-48-40-15-FUSA			2250			
LLS100-48-50-15-FUSA			2250			
LLS100-48-35-18-FUSA		18	2259	120/277VAC	>0.95	YES
LLS100-48-40-18-FUSA	48"		2520			
LLS100-48-50-18-FUSA			2520			
LLS100-48-35-20-FUSA		20	2948	120/277VAC	>0.95	YES
LLS100-48-40-20-FUSA	48"		3000			
LLS100-48-50-20-FUSA			3000			

©LEDLIGHTINGSOLUTIONS

DIRECT.410.320.0200 OFFICE.855.309.1702 FAX.941.296.7313


WWW.LEDLIGHTINGSOLUTIONS.COM

All rights reserved. LED Lighting Solutions reserves the right to change specifications for product improvement without prior notice.




# **INSTALLATION INSTRUCTIONS**


Inductance ballast type



Electronic ballast type



For more than one tube



- 1. Turn off the power to the light fixture at the breaker panel before installation.
- 2. Open the diffuser from the light fixture.
- 3. Remove the fluorescent tubes. Please dispose of these items properly as they contain mercury.
- 4. Open the wiring cover to expose the fluorescent ballasts.
- 5. Cut the wires as shown in the diagram above.
- 6. Make the new wire connections to the branch circuit as shown above.
- 7. Replace the cover over the wiring channel.
- 8. Install LED tubes and close the diffuser.